

*fitnessleisure*

Endurance, Stamina, Vitalizer

OWNER'S MANUAL



6101 45<sup>th</sup> St. N.  
St. Petersburg, FL 33714  
727.573.9611  
[www.PremiumLeisure.com](http://www.PremiumLeisure.com)

Part Number 7067

Revised 06/10

## Owner's Information

Dealer:

Date Purchased: \_\_\_\_\_  
Company: \_\_\_\_\_  
Address: \_\_\_\_\_  
Telephone: \_\_\_\_\_

Installer:

Date Installed: \_\_\_\_\_  
Company: \_\_\_\_\_  
Address: \_\_\_\_\_  
Telephone: \_\_\_\_\_

Hot Tub:

Date Delivered: \_\_\_\_\_  
Model: \_\_\_\_\_  
Color: \_\_\_\_\_  
Serial Number: \_\_\_\_\_

Your unique hot tub serial number is located on a data plate outside the cabinet at ground level directly below the topside control panel. When calling for service, have your serial number in hand.

MODEL 1005-LP-P-MA-NO-23  
SERIAL # #####  
12345678



# Fitness Leisure Hot Tub™ Owner's Manual

## Table of Contents

Introduction .....	2
Important Safety Information .....	<b>3</b>
Site Selection and Installation .....	7
Startup.....	20
Water Balancing .....	24
Topside Control.....	25
Cover.....	29
Frequently Asked Questions .....	30
Troubleshooting .....	33
Maintenance and Care .....	36
Specifications .....	40
Certificate of Verification .....	43

**Important:** Fitness Leisure is dedicated to offering you the best in customer satisfaction and service. Be sure to read, complete, sign, and **send in the limited warranty card within 30 days of purchase** to ensure you understand what you are entitled to in terms of service. If you have any questions, you can call our customer care center, at 727.573.9611.

Printed in the U.S.A.

Version 1.3

Revised 06/10

Part # 7067

Copyright © 2010, Premium Leisure LLC. All rights reserved. No portion of this manual may be reproduced in any manner without express written permission of Premium Leisure LLC. Fitness Leisure Hot Tubs™ and Thermazone™ are trademarks of Premium Leisure LLC. All other brands, product names, company names, trade names, trademarks, and service marks used are the property of their respective owners. Premium Leisure LLC may make product modifications and enhancements. Specifications may change without notice. International products may be configured differently to meet local electrical requirements. Dimensions are approximate. Patents pending.

---

## Introduction



Your choice of a Fitness Leisure Hot Tub™ indicates that you are devoted to excellence. The management and staff appreciate your patronage and takes pride in the tradition of quality hot tubs that our company represents.

To properly acquaint yourself with your hot tub, we suggest that you take time to read through this manual before hook up and operation. Doing so will familiarize you with important operating and safety procedures, thereby ensuring an enjoyable experience right from the start.

If you need any more information than this manual provides, feel free to visit our Web site at [www.PremiumLeisure.com](http://www.PremiumLeisure.com) or call our customer care center, at 727.573.9611.

**⚠ WARNING:** This manual was written to ensure the proper use and installation of your hot tub. Any modifications to the procedures outlined in this manual may result in voiding your warranty.

This manual and its contents are subject to change without notice. Although we have prepared this manual as accurate as possible, we are not liable for errors or omissions; loss, injury, or damages caused by improper installation; or use of hot tub (improper or otherwise).

Your new hot tub is made with quality synthetic cabinet materials. Synthetic materials won't fade and are nearly invulnerable to mold and mildew. Where wood splits, cracks, and stains, synthetic materials stand in timeless perfection.

## Important Safety Information


### IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS


Your physiological response to hot water depends on subjective factors such as age, health, pregnant women, temperature sensitivities, chemical sensitivities, and medical history. *Always* consult a physician before using a hot tub to understand your particular tolerance and limitations.

#### READ AND FOLLOW ALL INSTRUCTIONS





**WARNING** – To reduce the risk of injury, do not permit children to use this product unless they are closely supervised at all times.

A wire connector is provided on this unit to connect a minimum 8 American Wire Gauge (AWG) (8.4mm<sup>2</sup>) solid copper conductor between this unit and any metal equipment, metal enclosures of electrical equipment, metal water pipe, or conduit within 5 feet (1.5 m) of the unit.

**\* For cord connected / convertible units:**  **Danger – Risk of injury.**  
Replace damaged cord, immediately. Do not bury cord. Connect to a grounded, grounding type receptacle only.














**\*\* For units with GFCI:**  **Warning** – This product is provided with a ground-fault circuit interrupter located in the main panel. The GFCI must be tested before each spa use.

### Dangers

-  **RISK OF ACCIDENTAL DROWNING:** Extreme caution must be exercised to prevent unauthorized access by children. To avoid accidents, ensure that children cannot use this spa unless they are supervised at all times. Always cover the hot tub and use safety locks when it is not in use.
-  **RISK OF INJURY:** The suction fittings in this spa are sized to match the specific water flow created by the pump. Should the need arise to replace the suction fittings or the pump, be sure that the flow rates are compatible. Never operate the spa if the suction fittings are broken or missing. Never replace a suction fitting with one rated less than the flow rate marked on the original suction fitting.
-  **RISK OF ELECTRIC SHOCK:** Install at least 5 feet (1.5 m) from all metal surfaces. As an alternative, a spa may be installed within 5 feet of metal surfaces if each metal surface is permanently connected by a minimum 8 AWG (8.4 mm<sup>2</sup>) solid copper conductor to the wire connector on the terminal box that is provided for this purpose.
-  **RISK OF ELECTRIC SHOCK:** Do not permit any electric appliance, such as a light, telephone, radio or television, within 5 feet (1.5 m) of a spa. Do not operate such an appliance from either inside the hot tub or when you are wet, unless such appliances are built-in by the manufacturer.

## Warnings

### **TO REDUCE THE RISK OF INJURY:**

- The water in a spa should never exceed 40°C (104°F). Water temperatures between 38°C (100°F) and 40°C (104°F) are considered safe for a healthy adult. Lower water temperatures are recommended for young children and when spa use exceeds 10 minutes.
  - Since excessive water temperatures have a high potential for causing fetal damage during the early months of pregnancy, pregnant or possible pregnant women should limit spa water temperatures to 38°C (100°F).
  - Before entering a spa/hot tub, the user should measure the water temperature since the tolerance of water temperature regulating devices varies.
  - The use of alcohol, drugs or medication before or during spa/hot tub use may lead to unconsciousness with the possibility of drowning.
  - Obese persons and persons with a history of heart disease, low or high blood pressure, circulatory system problems, or diabetes should consult a physician before using a spa.
  - Persons using medication should consult a physician before using a spa/hot tub since some medication may include drowsiness while other medication may affect heart rate, blood pressure and circulation.
-  Do not connect auxiliary components (such as headphones, cables, and additional speakers) to the stereo (if equipped).
-  Do not use a hot tub immediately following strenuous exercise.
-  Do not use your hot tub alone.
-  Lock the cover on your hot tub when not in use.
-  Persons with infectious diseases should not use a hot tub.
-  Replace audio components only with identical components.
-  Do not leave the CD access door open on the stereo (if equipped).
-  Some types of hair dye can react with the sanitizers in your hot tub water causing your hair to change color. Use at your own risk.
-  Water normally splashes out of a hot tub during typical use. Install an adequate perimeter that provides sound footing.
-  Do not turn your hot tub on/off from a wall switch, ground fault circuit interrupter, circuit breaker, fuse, or by plugging/unplugging it.
-  Remove all jewelry, metal, and watches from your person before entering your hot tub.
-  Keep all breakables away from the hot tub area.
-  Maintain water balance in accordance with instructions.

## Warning Sign



**Warning Sign Must Be Posted** – The red WARNING sign like the one shown is packed with your new hot tub. This sign must be posted in a prominent place in close proximity to the hot tub installation site immediately upon completion of hot tub installation.

**Important:** It is extremely important that this sign be permanently placed in clear view of persons using the hot tub. Occasional hot tub users may not be aware of some of the dangers hot water poses to pregnant women, small children, seniors, and people under the influence of alcohol. If you did not receive a warning sign or your sign has become damaged, please call your local dealer for a replacement.

## Hyperthermia

To reduce the risk of injury, the water temperature in a hot tub should never exceed 104°F (40°C). Water temperatures between 100°F (38°C) and 104°F (40°C) are considered safe for a healthy adult. Lower water temperatures are recommended for young children, senior citizens, persons with sensitivities, and when hot tub use exceeds 10 minutes.

**WATER TEMPERATURE IN EXCESS OF 100°F (38°C) MAY BE INJURIOUS TO YOUR HEALTH.**

Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperature of 98.6°F (37°C). The symptoms of hyperthermia include drowsiness, lethargy, and an increase in the internal temperature of the body. The effects of hyperthermia include:

- ⚠ Unawareness of impending hazard
- ⚠ Failure to perceive heat
- ⚠ Failure to recognize the need to exit hot tub
- ⚠ Physical inability to exit hot tub
- ⚠ Fetal damage in pregnant women
- ⚠ Unconsciousness and danger of drowning

**If you sense any of the symptoms of hyperthermia, safely exit the hot tub immediately.**

**SAVE THESE INSTRUCTIONS**

---

## Basic Safety Guidelines

Your hot tub is meant to be enjoyable, healthful, and relaxing. Below are some basic safety guidelines to follow every time you use your hot tub.

- Always check the temperature of your hot tub before entering. High water temperatures can be hazardous to your health.
  - Persons suffering from heart disease, diabetes, high or low blood pressure, and pregnant women should consult a doctor before using your hot tub.
  - Persons under the influence of medication, drugs, or alcohol should not be allowed into your hot tub.
  - Remove all jewelry, metal, and watches from your person before entering your hot tub.
  - Do not allow children to use your hot tub without continuous supervision of an adult.
  - Do not use your hot tub alone.
  - Test the ground fault circuit interrupter (GFCI) breaker prior to using your hot tub each time to ensure it operates properly.
  - Any electrical devices near your hot tub must be GFCI protected and out of reach from inside the hot tub.
  - Keep all breakables away from the hot tub area.
  - Lock the cover on your hot tub when not in use.
  - Enter and exit the hot tub slowly. Wet surfaces can be slippery.
  - Prolonged immersion can be hazardous to your health.
- Maintain water chemistry in accordance with manufacturer's instructions.

## Site Selection and Installation


Proper planning is an important consideration when installing your new hot tub. Site selection is a critical step and requires serious thought. Planning ahead makes the installation process easier. The following information is provided to assist you in site preparations.

- 1) Always comply with local building codes and obtain any necessary permits. You may also need to consult with an engineer to address your specific design needs.
- 2) Contact an electrician to assess your electrical needs, install wiring, and assure a safe operation.
- 3) Position your hot tub with proper access to water, drainage, and electricity.
- 4) Place your hot tub on a uniform solid, flat surface designed to properly support its weight. For external installations, a 4-inch (10 cm) thick cement pad suffices. See page 8 for conduit entry locations for your model hot tub.
- 5) For internal installations, check the load carrying capabilities of the floor on which the hot tub will reside. Most homes meet the requirement of 80 pounds per square foot.
- 6) Assure that your hot tub will fit into the space you have chosen and the delivery route will accommodate its large size.
- 7) Provide adequate ventilation for the humidity created by your hot tub. In most cases, a Hot Tub Hard Cover is sufficient.
- 8) Protect the pump and all equipment from the weather by ensuring the cabinet panels are secure at all times.
- 9) Allow 36 inches (1 meter) of unobstructed access to all sides of your hot tub for normal servicing. Your hot tub is not designed to be recessed in the ground or in a deck.



**Figure 1 – Clearances and Support**

The following dimensions can be used to determine the proper location of submerged conduits in concrete slab installations. All dimensions are made from the outside of the hot tub's frame with the access panels removed. The topside control panel is shown at bottom of diagram for reference.



**Figure 2 – Conduit Entry Location Reference Points**

Model	Dimension A	Dimension B
Endurance	Call	Call
Stamina	18" (46cm)	9" (23cm)
Vitalizer	Call	Call

**Table 1 – Conduit Entry Location Dimensions**

- 10) Consider positioning your hot tub out of or adequately protecting it from the wind. Just as people can get cold on cool/windy days, so can your hot tub. Windy environments can significantly increase operating costs.
- 11) Consider using an insulating pad. In cold climates, the ground can rob heat from the hot tub and increase your operating costs.

## Electrical Specifications

**Important** – Qualified and licensed electricians must perform all electrical hookups. The following specifications must be followed in order to ensure proper performance and safety.

**⚠ WARNING:** Starting an incorrectly wired hot tub could cause severe damage to the mechanical equipment or even bodily harm. Have your licensed electrician verify GFCI (or RCD) wiring with the diagrams on pages 10-19, prior to starting the hot tub or call the technical support line at 727.573.9611.

**⚠ Caution:** Failure to abide by specifications listed may result in damage to the equipment and will void the warranty.

All hot tubs must be wired with the appropriately sized wiring. Failure to do so will cause equipment damage and will not be covered under your warranty.

All hot tubs must be over current protected with a built-in GFCI (or RCD for export models) in the service panel.

Model	Volts (V)	Freq. (Hz)	Rating (A)	GFCI (A)	Wire size from GFCI to Main Panel <sup>†</sup>	Equipment Pack
Endurance (ER 11)	240	60	40	50	6-3 plus ground (up to 130') 4-3 plus ground (up to 230') 2-3 plus ground (up to 360')	VS515Z
Stamina <sup>‡</sup> (SQ09)	240	60	40	50	6-3 plus ground (up to 130') 4-3 plus ground (up to 230') 2-3 plus ground (up to 360')	VS500Z
Stamina <sup>‡</sup> (SQ09) Vitalizer (OV10)	120	60	16	20	12-2 plus ground (up to 130') 10-2 plus ground (up to 230') 8-2 plus ground (up to 360')	VS500Z

Table 2 – Wire Size Chart

Model	Volts (V)	Rating (A)	RCD (A)	Wire size from RCD to Main Panel <sup>§</sup>	Equipment Pack
All	220-240	1x32 2x16	IEE Wire Regulation	3x4 mm <sup>2</sup> 5x1.5 mm <sup>2</sup>	GS510SZ

Table 3 – Export (Overseas) Wire Size Chart

**⚠ WARNING:** Disconnect electrical power before servicing. Before obtaining access to terminals, all supply circuits must be disconnected.

**⚠ WARNING:** Test the GFCI (or RCD) before each use.


\* Wire size may need to be reduced at GFCI to fit into the breaker

† Solid copper

‡ Stamina is available in either 120V or 240V versions


§ Solid copper





**Figure 5 – U.S. and Canada Wiring Diagram**


See wire size chart on page 9.



**Figure 6 – European 1x32A Wiring Diagram**

All wiring is 3x4 mm<sup>2</sup>, solid copper  
See wire size chart on page 9.

**Note:** Make sure that the DIP switches in the hot tub Pack are properly set for 50Hz operation and Jumper A is in place.



**Figure 7 – European 2x16A Wiring Diagram**

All wiring is 5x 1.5 mm<sup>2</sup>, solid copper  
See wire size chart on page 9.

**Note:** Make sure that the DIP switches in the hot tub Pack are properly set for 50Hz operation and Jumper A is removed.





Figure 8 – VS500Z Board Diagram for Vitalizer and Stamina Models  
Single-phase 240V Domestic Version

**WARNING:** Main Power to system should be turned OFF BEFORE adjusting DIP switches.  
**WARNING:** Persistent Memory (J43) must be RESET to allow new DIP switch settings to take effect. (See Persistent Memory page)





**Figure 9 – Board Diagram and Panel Positions for Vitalizer and Stamina Models Single-phase 240V Domestic version**

## SSID 100 61 43


## Base Model VS500Z

### DIP Switch Key

- A1 Test Mode (normally OFF)  
A2 "ON" position: Button layout will be: Pump 1, Light, Temp Down, Temp Up \*  
"OFF" position: Button layout will be: Unused, Pump 1, Temp, Light  
A3 "ON" position: use Mini Panel \*   
"OFF" position: use Lite Duplex or Digital Duplex panel   
A4 Aux Freeze (must be OFF)  
A5+A9 Pump 1 speeds and Circ Modes:

A5	A9	Circ Mode	Pump 1 Speed
OFF	OFF	Non-circ	2-speed
ON	OFF	Circ "acts like Pump 1 low" (filters/polls/ect)	1-speed
OFF	ON	24 hours with 3°F shut-off	1-speed
ON	ON	24 hours with 3°F shut-off	2-speed

- A6 "ON" position: 50Hz operation  
"OFF" position: 60Hz operation  
A7 "ON" position: Standard mode only  
"OFF" position: Std/Ecn/Sleep mode changes allowed  
A8 "ON" position: temperature is displayed in degrees Celsius  
"OFF" position: temperature is displayed in degrees Fahrenheit  
A10 "ON" position: heater is disabled while any high-speed pump is running (low amperage mode)  
"OFF" position: heater can run while any/all high-speed pumps are running (high amperage mode)

\* Panels with button layout  are not compatible when A2 or A3 is ON.

Note: No blower or second pump available on VS500Z model. If additional output is required, use VS501Z or higher.

### Jumper Key

#### J12 Factory set. DO NOT MOVE.

Jumper must be on Pins 1 and 2 for VS51xZ/VS52xZ/VS5xxSZ/VS5xxDZ software.  
Jumper must be on Pins 2 and 3 for VS50xZ software.

- J43 When jumper is placed on 2 pins during power-up, system will reset persistent memory.  
Leave on 1 pin only to enable persistent memory feature.

### WARNING:

- Setting DIP switches incorrectly may cause abnormal system behavior and/or damage to system components.
- Refer to Switchbank illustration on Wiring Configuration page for correct settings for this system.
- Contact Balboa if you require additional configuration pages added to this tech sheet.




Figure 10 – VS515Z Board Diagram for Endurance Model Single-Phase, 240-Volt Domestic Version

**WARNING:** Main Power to system should be turned OFF BEFORE adjusting DIP switches.  
**WARNING:** Persistent Memory (J43) must be RESET to allow new DIP switch settings to take effect. (See Persistent Memory page)






Figure 11 – Board Diagram and Panel Positions for Endurance Model Single-phase 240V Domestic version

## SSID 100 58 43

## Base Model VS515Z

### DIP Switch Key

- A1 Test Mode (normally OFF)
- A2 "ON" position: Standard mode only  
"OFF" position: Std/Ecn/Sleep mode changes allowed
- A3 "ON" position: use Mini Panel   
"OFF" position: use Digital Duplex or Light Duplex panel 
- A4 Aux Freeze (must be OFF)
- A5 "ON" position: Expander Board Enabled for 1-speed Pump only.  
"OFF" position: Expander Board Disabled.
- A6 "ON" position: 50Hz operation  
"OFF" position: 60Hz operation
- A7+A10 Control amp draw requirements (See Table 1)
- A8 "ON" position: temperature is displayed in degrees Celsius  
"OFF" position: temperature is displayed in degrees Fahrenheit
- A9 "ON" position: J17/26 Enabled for Blower or 1-speed Pump.  
"OFF" position: J17/26 Disabled

Note: For Panel layout See Chart below.

**Alert:**  
Circ Pump is not allowed on this system.

AZ	A10	# of Hi-Speed Pumps/Blower Before Heat Disabled
OFF	OFF	0
ON	OFF	1
OFF	ON	2
ON	ON	3

### Jumper Key

- J12** **Factory set. DO NOT MOVE.**  
Jumper must be on Pins 1 and 2 for VS51xZ/V552xZ/V55xxSZ/V55xxDZ software.  
Jumper must be on Pins 2 and 3 for VS50xZ software.
- J43** When jumper is placed on 2 pins during power-up, system will reset persistent memory.  
Leave on 1 pin only to enable persistent memory feature.

### WARNING:

- Setting DIP switches incorrectly may cause abnormal system behavior and/or damage to system components.
- Refer to Switchbank illustration on Wiring Configuration page for correct settings for this system.
- Contact Balboa if you require additional configuration pages added to this tech sheet.




Figure 12 – VS510SZ Board Diagram for All EXPORT Models

**WARNING:** Main Power to system should be turned OFF BEFORE adjusting DIP switches.  
**WARNING:** Persistent Memory (J43) must be RESET to allow new DIP switch settings to take effect.




Figure 13 – Board Diagram and Panel Positions for all EXPORT Models

**SSID 100 65 43 Base Model GS500SZ-GS501SZ-GS510SZ**

**DIP Switch Key**

- A1 Test Mode (normally OFF)
- A2+A10 Control amp draw requirements (See Table 1)
- A3 "ON" position: Expander Board Enabled for 1-speed Pump only.\*  
"OFF" position: Expander Board Disabled.
- A4 Aux Freeze (must be OFF)
- A5+A9 Pump 1 speeds and Circ Modes:

A5	A9	Circ Mode	Pump 1 Speed
OFF	OFF	Non-circ	2-speed
ON	OFF	Circ "acts like Pump 1 low" (filters/polls/ect)	1-speed
OFF	ON	24 hours with 3°F shut-off	1-speed
ON	ON	24 hours with 3°F shut-off	2-speed

		# of Hi-Speed Pumps/Blower Before Heat Disabled
A2	A10	
OFF	OFF	0
ON	OFF	1
OFF	ON	2
ON	ON	3

- A6 "ON" position: 50Hz operation  
"OFF" position: 60Hz operation
- A7 "ON" position: J17/26 Enabled for Blower or 1-speed Pump.\*  
"OFF" position: J17/26 Disabled
- A8 "ON" position: temperature is displayed in degrees Celsius  
"OFF" position: temperature is displayed in degrees Fahrenheit

\* Panel with button layout (Ⓜ) is not compatible when both A3 and A7 are ON.



**Panel Button Assignments (A2 must be OFF)**

- 1=Mode
- 2=Temp Up
- 3=Temp Down
- 4=Light
- 5=Pump 1
- 6= Pump 2

Figure 14 – Panel Button Positions for export models.


## Startup

**Important** – Read these step-by-step startup procedures before starting your hot tub. Failure to follow any of these steps listed may result in damage to the equipment and may void your warranty.

**Note:** If you are unsure of any of the above startup procedures, please call our customer care center, at 727.573.9611. For best results, read each step in its entirety before proceeding.

**⚠ Caution:** Running the hot tub pump dry (without water running through it) can cause IMMEDIATE damage and will void the warranty! Be sure that the hot tub is installed properly in accordance with the instructions in this manual.

Refer to the following picture for an explanation of your hot tub's controls, components, and technical terms. Note that not all models have all features and components.



**Figure 15 – Callouts**

## Before Adding Water

Before adding water, go through these simple steps now to prevent common issues when setting up your hot tub for the first time. Verify that the following have all been rechecked.

1. Turn off all power to the hot tub at the main breaker panel.
2. Open the side panels to access the internal components.
3. Check that all slide valves are opened (T-handles pulled out) to the heater and all pumps.
4. Check that there are no obvious signs of loose wires or broken pipes.



Figure 16 - Valve Open/Closed

5. Check that the two heater unions are hand tight.

**⚠ Caution:** Do not use a wrench. Over-tightening may cause damage to unions and gaskets, which will not be covered under warranty.



Figure 4 - Unions Tight

6. Check that the unions on all pumps are tight.
7. Clean out any foreign debris from within the service access area or inside of the hot tub itself.
8. With the drain open and filters removed, thoroughly rinse out the hot tub with warm water until the drained water runs clear. Run water through the filtration canister and jet lines to remove any incidental dust, dirt, and debris that may have accumulated during shipment or installation. Drain all water completely.
9. Make sure that the hot tub drain valve is closed and the cap is on tight (see page 37).
10. Install the filter(s) in the filtration canister.
11. Check that all of the hot tub jets are open (turned full counter-clockwise).
12. Now is the best time to clean and polish the surfaces of your hot tub (see pages 31).

## Filling Your Hot Tub

Now it's time to fill your hot tub with water. Do not turn on the electricity yet until the hot tub is completely filled. To properly fill your hot tub:

1. Make sure that the filters (in the filtration canister) are gently screwed into place. Turn them clockwise until they stop being careful not to over-tighten them (this avoids cracking the filter).
2. Connect a standard garden hose to a faucet with regular cold tap water (not softened water or hot water).



Figure 5 – Filtration Canister

**⚠ Caution:** The water from your hot water tank should not be used to fill the hot tub.

3. Put the pre-filter (if equipped\*\*) on the other end of the hose, point the pre-filter into a suitable drain, turn on the water, and allow any sediment to be flushed down the drain. Once the water stream runs clear, turn off the hose.
4. Put the pre-filter (if equipped) into the filtration canister and turn on the hose.
5. **Fill slowly.** If too much water pressure is used, foaming water can force air into the pipes and cause startup problems.

**Important:** To assure that the pump is properly primed, **fill the hot tub through the filter area only.**

6. Fill the hot tub until the water level is about 1" above all jets (or about ½" below the pillow). Do not over fill.

**Note:** Every person entering a hot tub displaces a given volume of water, so adjust water level to the number of people regularly using the hot tub.

Turn off the hose and check again for any small leaks.

## Operational Checks


**⚠ Caution:** Do not turn on any pump until your hot tub is properly filled with water. Running any pump without water in your hot tub can cause IMMEDIATE damage, which is not covered under warranty!

By now you have rechecked your hot tub's mechanical connections and filled it with water to about 1" above all jets by adding cold tap water through the pre-filter (if equipped). Turn on power to the hot tub at the main breaker panel and test the operation of the electrical system. If you encounter a problem, please reference the troubleshooting guide on page 33.

---


\*\* Pre-filters are available by calling 877.530.PARTS

1. Turn on the breaker and test the operation of the Ground-Fault Circuit Interrupter (GFCI) breaker by pushing the small button. This should automatically trip the hot tub's circuit breaker.

 **DANGER:** If this breaker does not trip, immediately call your electrician. Do not use your hot tub!

Only if pushing this button successfully trips this circuit breaker should you reset this breaker and proceed to the next step.

2. Go to the topside control panel. The hot tub first goes into a 5-minute Priming mode, indicated by "Pr" message. Water heating is disabled during priming. To exit Priming mode and begin normal hot tub operation, press "Up" or "Down" button.
3. Press the Jets button. You should hear the pump turn on, see water circulating, and see the Jets light illuminate on the panel.
4. Press the Jets button again. You should hear the pump turn on a higher speed.

 **Caution:** If water is not flowing from the jets after 2 minutes, turn the power off at the main panel and bleed air from the system (see page 30). Turn the power on again. Sometimes momentarily turning the pump off/on will help to prime. Only do this four times.

5. If the water is running smoothly through the lines, open the air control valve to the jets and you should see an increase in jet pressure. Check and adjust the water and airflow of every jet if necessary.

Each jet in your hot tub can be adjusted for massage intensity and directional flow. Turn the outer jet dial counterclockwise to increase the water volume and clockwise to turn it off. Pivot the angle of a jet to achieve an optimal massage.

An air mixture intensifies the level of your massage. Turn the air control valve counterclockwise to increase the air mixture and clockwise to turn it off.

To minimize heat loss, close the air control valve when the hot tub is not in use.

6. Press the Jets button a third time to turn off the pump.

**Note:** The pump remains on if filtration or heat is needed.


7. Press the Light button to turn on the light. Verify that the light is on.
8. Press the Light button a second time to turn off the light.
9. If equipped, press the Blower button. You should hear the blower turn on, see water bubbling, and see the blower light illuminate on the panel.
10. Press the Blower button again to turn off the blower.
- 11.

# Water Balancing

**Note:** Perform water balancing weekly and whenever your water is changed (or when the hot tub is first filled) to assure proper water condition.

Once your hot tub reaches 95°F, use our *Bromine Test Strips* (not included) and add the necessary chemicals (not included) to stabilize your water chemistry. Turn Pump 1 on high speed before starting your tests to distribute chemicals evenly. Wait 5 minutes between measurements to allow added chemicals to mix thoroughly.

**Important:** Test the condition of your water in the following order:

1. **Total Alkalinity** (80-120 ppm) – Use our *Alkalinity Increaser* to raise total alkalinity and *Alkalinity Decreaser* to lower it. Low total alkalinity has little buffering capacity making the pH erratic. High total alkalinity has too much buffering capacity making the pH difficult to change.
2. **pH** (7.2-7.8) – Use *Spa Up* to raise the pH level and *Spa Down* to lower it.  
 **Caution:** A pH lower than 7.2 can harm the metal surfaces of your hot tub and irritate your eyes and skin. A pH higher than 7.8 can create calcium deposits (scaling) on the shell and equipment.
3. **Hardness** (150-400 ppm) – Add *Increase Calcium* until the proper level is achieved. Unfortunately, there is no practical way to lower the native water hardness other than using a different source of water when filling your hot tub. Low hardness causes equipment corrosion and water foaming.
4. **Sanitizer** (3.0-5.0 ppm) – Use our *Deluxe Bromine Kit* to add Bromine until the proper level is achieved. Neglected hot tub water can breed bacteria and algae causing bather discomfort, skin rashes, and/or irritation.

Test	Range
Total Alkalinity	80-120 ppm
pH	7.2-7.8
Calcium Hardness	150-400 ppm
Sanitizer	3.0-5.0 ppm

**Table 4 - Recommended Ranges for Balanced Water**

# Topside Control

## Programming Instructions Domestic



Figure 6A – Vitalizer and Stamina Topside Control Panel  
(MVP 260 Domestic)

### Lamps

- When the *Jets* lamp is on steady, the system is in a filtration cycle.
- When the *Temp* lamp is flashing, the system is checking the water temperature.
- When the *Temp* lamp is on steady, the system is heating the water.

### Water Temperature

Press *Cool* or *Warm* to select the desired temperature. The desired temperature setting displays for five seconds to confirm your new selection and then displays the actual water temperature. The default temperature is 100°F.

### Filtration Cycle

**Start Time** – Reset the controller by power cycling (power off). After the five minute priming, the filtration cycle starts 12 hours later. To skip the priming period, press *Cool/Warm*.

**Duration** – Press *Cool/Warm*, then *Jets*. Press *Cool/Warm* to adjust to 2, 4, 6, or 8 hours, or to continuous filtration (as indicated by FC on the display). Press *Jets* to exit. The default duration is 2 hours.

**Frequency** – The filtration frequency is fixed at twice a day.

### Standard, Economy, and Sleep Modes

Press *Cool/Warm* and then *Light* to set the operating mode. Press *Light* to advance between modes.

**Standard** (Std) mode maintains the desired water temperature all the time.

**Economy** (Ecn) mode turns on the heater only during filtration cycles and tries to maintain the desired water temperature.


**Sleep** (SLP) mode turns on the heater only during filtration cycles and drops the water temperature 20°F (11°C) below the desired water temperature.

**Note:** Some models may use the following topside control where you have one “TEMP” button to control the temperature and one “AUX” button to control the Air Jet Bubbler (blower).



**Figure 19B – Endurance Topside Control Panel (MVP260 Domestic)**

## Programming Instructions Export



**Figure 20 – Topside Callouts for VL600S Controls**

### Initial Start Up

When your hot tub is first actuated, it will go into Priming mode, indicated by “Pr.” The priming mode will last for less than five minutes. Press “WARM” or “COOL” to skip Priming Mode and then the hot tub will begin to heat and maintain the temperature in “Standard Mode.”

### Warm/Cool Buttons (Set Temperatures between 80°F - 104°F / 26°C - 40°C)

The startup temperature is set at 100°F/37°C. The last measured temperature is constantly displayed on the LCD and is current only when the pump has been

running for at least two minutes. To **display** the set temperature, press the “WARM” or “COOL” button once. To **change** the set temperature, press the “WARM” or “COOL” button a second time before the LCD stops flashing. Each press of the “WARM” or “COOL” button will continue to raise/lower the set temperature. After three seconds, the LCD will stop flashing and display the current hot tub temperature.

### **Jets Button**

---

Press the “JETS” button once to activate the low speed of Pump 1. Press it a second time to activate the high speed of Pump 1. Press it a third time to turn off Pump 1. If left running, the high speed of Pump 1 automatically will turn off after 15 minutes and the low speed of Pump 1 automatically will turn off after 4 hours.

The low speed of Pump 1 runs when the “AUX” Blower (if equipped) is on. It may also active for at least two minutes every half hour to detect the hot tub temperature and then to heat to the set temperature if needed (depending on mode). When the low speed turns on automatically, it cannot be deactivated from the panel, however the high speed may be activated.

### **Aux Button**

---

Press the “AUX” button once to turn on Blower (if equipped). Press it a second time to turn off Blower. If left running, Blower automatically will turn off after 15 minutes.

### **Light**

---

Press the “LIGHT” button once to turn on your hot tub lights. Press the LIGHT button multiple times to cycle through the many available color patterns. Press the LIGHT button again to turn off the LED light system. If left on, the lights automatically turn off after 4 hours.

### **Mode**

---

Your hot tub operating mode is changed by first pressing the “WARM” or “COLD” button, then pressing the “MODE” button.

- **Standard Mode** is programmed to constantly maintain the desired temperature. “*Std*” will be displayed momentarily when you switch into standard mode.
- **Economy Mode** heats the spa to the set temperature *only* during filter cycles. “*Ecn*” will display solid when temperature is not current and will alternate with temperature when temperature is current.
- **Sleep Mode** heats the hot tub to within 20°F/10°C of the set temperature *only* during filter cycles. “*SLP*” will display solid when temperature is not current and will alternate with temperature when temperature is current.

### **Preset Filter Cycles**

---

The first filter cycle begins six minutes after the hot tub is energized. The second filter cycle begins 12 hours later. Filter duration is programmable for 2, 4, 6 or 8 hours – or for continuous filtration indicated by “*FLC*.” The default filter time is

two hours.

To program filter cycles, press “WARM” or “COOL” and then “JETS.” Press “WARM” or “COOL” again to adjust to your desired setting. Press “JETS” again to exit filter cycle programming.

The low speed of the 2-speed pump runs during filtration and the ozonator will be enabled.

### Smart Winter Mode



If the system (sensor located inside heater) detects ambient conditions below 44°F/6.7°C, it automatically enters the Smart Winter Mode for period of four minutes after it detects the hot tub temperature has risen to 45°F/7.2°C.

### Programming Summary





Figure 21 – VL600S Programming Summary

NOTE FOR THE MVP 260 TOPSIDE CONTROLS:

- Follow the above steps to set the filter cycle and water temperature.
- To set the operating modes domestically with the MVP 260 controls, follow the steps above *except* instead of pressing “Mode” – press “LIGHT.”

## Cover

Place the insulated cover on your hot tub. Keeping the cover in place anytime the hot tub is not in use reduces the heating time and minimizes operating costs. The time required for initial heat-up varies depending on the starting water temperature, ambient temperature, and the capacity of your hot tub.



**Figure 22 - Cover Callouts**

- |                                |                                     |
|--------------------------------|-------------------------------------|
| 1. Lock-down tab               | 7. Heat-sealed insulation           |
| 2. Double-stitched seams       | 8. Chemical-resistant vapor barrier |
| 3. Marine-grade cover material | 9. Polystyrene seam stoppers        |
| 4. Edge overlap material       | 10. Reinforced edges                |
| 5. Grip handle                 | 11. Breathable underside material   |
| 6. Aluminum channel            |                                     |

Use the lock-down tabs to prevent access to the hot tub by children and to prevent the wind from lifting the cover off.



**Figure 23 -  
Lockdown Tabs**

Sitting, standing, and snow buildup on the cover will break the cover. Dragging it over rough surfaces will scuff or tear the fabric. Always lift by the handles or use the optional cover lift device.

## Frequently Asked Questions

### Who do I call for warranty information or service?

Call our customer care center between 8AM and 5PM EST Monday through Friday at 727.573.9611. Our representatives are eager to assist or you can get help online at [www.FitnessSpas.com](http://www.FitnessSpas.com).

### Who are the service companies in my area?

Fitness Leisure contracts with several service companies in your area to ensure the best possible response time. Our customers are guaranteed to receive service response priority. If you encounter a matter that can't be easily resolved over the phone, a local technician can be dispatched to your home. The service technician may assess reasonable travel charges during on-site repairs. Call our customer care center, at 727.573.9611.

### How do I bleed air from my system?

When draining and refilling your hot tub, the pump may become air locked. Air-locked pumps stop water from flowing in your hot tub and is easily resolved by bleeding off the trapped air. To do this:

1. Turn off the GFCI breaker
2. Open the access panel below the topside control panel
3. Loosen a heater union until you hear the trapped air escape
4. Once water drips out in a continuous stream, hand tighten the union until the water stops leaking
5. Once water drips out in a continuous stream, hand tighten the union until the water stops leaking
6. Turn on all pumps to make sure that there are no leaks
7. Put the access panels back on
8. Turn on the GFCI breaker



**Figure 24 - Bleeding Air**

## What happens when my warranty expires?

Fitness Leisure will continue to provide service for your hot tub after your warranty has expired via our customer care center at 727.573.9611.

## Where can I get more Chemicals or other accessories?

Visit [www.hottubparts.com](http://www.hottubparts.com) or call 877.530.PARTS.

## How should I clean my hot tub?

Use non-sudsing cleaners and non-oily polishes (see page 38). Our Citra Bright Spray Cleaner and our Tub Rub cleaning pad quickly removes scum lines and helps restore your shell's original beauty. Rinse all filters, covers, pillows, and surfaces thoroughly with warm tap water. Our Filter Clean concentrated cleanser is a safe, effective way to clean and re-use your filters and our Jet Clean plumbing cleanser cleans the inside of all plumbing in your hot tub. Call 727.573.9611 to order these easy-to-use cleaning products.

## How often should I drain my hot tub?

You should drain and refill your hot tub every 1-3 months depending on usage. Every other time you drain and refill, you should also replace the filters and wipe down the hot tub (see page 37).

## How do I adjust my jet?

Simply turn the jets counterclockwise to open and clockwise to close. Be careful not to overturn the jets, as damage can occur.


**⚠ Caution:** Do not turn off too many jets at the same time. This can create backflow and possible damage to your hot tub!

## Are the jets removable? Interchangeable? Replaceable?

Most jets are made removable and adjustable for customized hydrotherapy.

## What is the insulation made of?

We use a Thermazone™ process to fully insulate all of our hot tubs. First, the bottom of each shell is blanketed with a thick layer of solid-cell, high-density insulating foam. Second, an layer of insulation is added to interior of the cabinet. Third, an air-tight base prevents heat loss. Fourth, a 5-inch thick insulating cover is included.



---

## What is the shell made of?

We use Lucite® Cast Acrylic with Microban® Antimicrobial Protection for all of our hot tub shells.

Microban antimicrobial product protection is built-in to Lucite acrylic during the manufacturing process to help prevent the growth of stain causing bacteria on the surface of the hot tub.

Microban protection works continuously to keep the surface of the hot tub cleaner and won't wash off or wear away for protection that lasts the lifetime of the hot tub.



**HotTubParts.com**  
Spa Parts & Accessories  
**Authorized Dealer**

## Troubleshooting

If a problem arises, you can check this list for a quick solution. If this does not resolve your problem, please call our customer care center, at 727.573.9611. Additional information is also available at [www.FitnessSpas.com](http://www.FitnessSpas.com). You will need your serial number to access this site.

**Important** – Most problems can be quickly resolved by resetting the GFCI breaker. Try this first before proceeding.

PROBLEM	CAUSE	SOLUTION
<b>Breaker trips</b>	Wiring error	Load Neutral wire not connected to GFCI (connected to Neutral bus)
	Wrong GFCI	GFCI breaker is wrong size
	Ozonator (or blower) wet	Remove tube from ozonator (or blower) and allow 2 days to dry out
<b>Foamy water</b>	Soaps, skin oils, or undissolved sanitizer particles	Close the air control valves and allow filtration cycle to run Add defoamer Drain and clean your hot tub Clean or change filters Rinse all bathing suits before bathing
<b>Leak</b>	Loose connection	Check and hand-tighten unions at heater & pumps, or clamps on jets
	Drain open	Close drain valve or replace cap
<b>Light doesn't work</b>	LED burnt out	Replace bulb
	Loose wire	Check wiring harness to LED
	Loose plug	Reseat J20 plug on hot tub pack
<b>Low/no jet pressure</b>	Air lock	Bleed air from the system (page 30)
	Dirty filter	Check and clean or replace filter
	Closed jets	Open all jets by turning CCW
	Closed valves	Open all T-handle shutoff valves on heater and pumps
	ACV open	Close air control valves
<b>Moved my hot tub and now it doesn't work</b>	Low water	Fill hot tub 1" above all jets
	Wiring error at GFCI	Check Neutral wiring of GFCI (see diagrams on pages 10-19)
<b>Nothing works</b>	No power to hot tub	Reset circuit breakers on GFCI panel and main circuit breaker panel
	Breaker has tripped	Check and reset breaker. If problem persists, check for loose electrical connections. Check for Neutral wiring error at GFCI.
<b>Pump not running</b>	Fuse blown	Check for blown Fuse 4 (F4) inside of spa pack.
	No power to hot tub	Reset circuit breakers on GFCI panel and main circuit breaker panel

PROBLEM	CAUSE	SOLUTION
<b>Water does not flow</b>	Air lock	Bleed air from the system (page 31)
	Closed jets	Open all jets by turning counterclockwise
	ACV open	Close air control valves
<b>Water too hot</b>	High set temperature	Turn down set temperature on topside control panel
	High ambient temperature	Remove the cover
<b>Water will not heat</b>	Thermostat is set too low	Check and reset to desired temperature
	Air open	Close air control valve
	Dirty filter	Check and clean filter
	Blown fuse	Check and replace fuse
	Slide valve closed	Check and open all valves
	Cover off	Put the cover back on
	Hot tub in Economy mode	Press the Standby button and take out of Economy (see <i>Economy Mode</i> on pages 25/27)

### Error Codes

MESSAGE	MEANING	ACTION REQUIRED
(none)	No message on display. Power has been cut off to hot tub.	The control panel is disabled until power returns. Hot tub settings are preserved.
<b>OHH HH</b>	The hot tub has shut down from high heat detection. One of the sensors detected 118°F (48°C) at the heater.	Do not enter the water. Remove the cover and allow the water to cool. Once cool, push any button. If the hot tub does not reset, turn off the GFCI and call service.
<b>OHS OH</b>	The hot tub has overheated and shut down. One of the sensors detected that the hot tub water is 110°F (43°C).	Do not enter the water. Remove the cover and allow the water to cool. At 107°F (42°C), the hot tub resets automatically. If the hot tub does not reset, turn off the GFCI and call service.
<b>ICE IC</b>	Potential freeze condition detected (Ice)	No action required. The pump will automatically operate regardless of the hot tub status.

MESSAGE	MEANING	ACTION REQUIRED
<b>SnA</b> <b>SA</b>	Sensor A is not working correctly. Hot tub is shut down.	Check the sensor "A" plug connection to circuit board. The problem may appear temporarily in an overheat situation and disappear when the heater cools. If the problem persists, contact service.
<b>SnB</b> <b>SB</b>	Sensor B is not working correctly. Hot tub is shut down.	Check the sensor "B" plug connection to circuit board. The problem may appear temporarily in an overheat situation and disappear when the heater cools. If the problem persists, contact service.
<b>SnS</b> <b>Sn</b>	Sensors are out of balance.	If this alternates with the temperature, it may be temporary. If the display shows only this message (periodically blinking), the hot tub is shut down. If the problem persists, contact service.
<b>HFL</b> <b>HL</b>	A substantial difference between sensors was detected (possible flow problem).	Check water level in hot tub and add water if necessary. Be sure that slide-valves are open. Make sure the pump is primed and has power. If the problem persists, contact service.
<b>LF</b>	<i>Low Flow</i> – persistent problem. Displays after the fifth occurrence of the "HL" message within 24 hours. Heater shuts down but other hot tub functions run normally.	Heating ability of the hot tub will not reset automatically; press any button to reset.
<b>dr</b>	Inadequate water, poor flow, or air bubbles detected in the heater. Hot tub is shut down for 15 minutes.	Check the water level and add water if necessary. Be sure that slide-valves are open. Make sure the pump is primed and has power. Press any button to reset (automatically reset within 15 minutes). If the problem persists, contact service.
<b>drY</b> <b>dy</b>	Inadequate water detected in heater. Displays on third occurrence of "dr" message. Hot tub is shut down.	Check water level in hot tub. Add water if necessary. Be sure that slide-valves are open. Make sure the pump is primed and has power. Press any button to reset.
<b>Pr</b>	When the hot tub is first activated, it goes into Priming mode.	The Priming mode runs for up to four minutes and then the hot tub begins to heat and maintain the water temperature in Standard mode.
<b>- - F</b>	Temperature unknown	After the pump has been running for two minutes, the temperature will be displayed.

MESSAGE	MEANING	ACTION REQUIRED
-- C	Temperature unknown	After the pump runs for two minutes, the temperature displays
---	Temperature not current	The hot tub is in either Economy or Sleep modes and the pump has not run for a while. To view the current temperature, switch to Standard mode or operate Jets 1 for at least one minute.

## Maintenance and Care

**Important** – The warranty on your hot tub and equipment depends on proper sanitation (see page 38). In addition, the following maintenance procedures must be followed periodically.

### Cabinets

Your cabinet is made from a polymer that combines the durability of plastic with the beauty of simulated wood. To clean the cabinet, a mild soap and water solution easily removes residue.

### Cover

The 5-inch thick tapered cover on your hot tub is made from a weatherproof marine-grade vinyl. Your cover will last much longer if you heed the following suggestions:

- 1) Don't drag the cover on the ground; wearing of the vinyl could easily develop into a tear.
- 2) The insulating foam in your cover is not designed to hold the weight of a person or an animal.

**Important** – Cracked foam in the cover is not covered under warranty! Do not stand on it.

- 3) Occasionally clean the inside of your cover with our special All Purpose Cleaner rinsed with warm water. (Using soap or vinyl cleaners on the inside of your cover causes foamy water.) Call our order line at 727.573.9611 to order our All Purpose Cleaner.
- 4) Our special Vinyl Cover Cleaner applied to the outside of the cover and stitching once yearly will keep your cover looking better longer. Call our order line at 727.573.9611 to order our special Vinyl Cover Cleaner.
- 5) Do not lift the cover by the safety straps, they are made to secure the tub to the cabinet and may tear.

## Draining and Refilling




Figure 25 - Drain Operation

- 1) Turn off the GFCI breaker.
- 2) Remove hot tub cover and allow water to cool down.
- 3) Select a safe, suitable drainage area capable of safely assimilating 300 plus gallons of water that may contain unsanitary contaminants and chemical residue that could cause harm to plants or grass.
- 4) Locate drain valve at front of the hot tub. Hold the rear body to prevent it from turning, then loosen and remove the front cap.
- 5) Attach a garden hose to the exposed threads and route the hose downhill to your drainage area.
- 6) Twist the drain fitting 1/3 turn counterclockwise to unlock the drain valve and pull it outward to open completely. The water will drain by gravitational flow.
- 7) After the hot tub drains, perform steps 3-5 in reverse order to close the drain prior to refilling hot tub.
- 8) Attach the garden hose to a thoroughly-flushed pre-filter (not included, rinsed of all residual sediment) and refill your hot tub through the filtration canister.
- 9) After refilling, turn on the GFCI breaker to the hot tub.

If the pump runs but no water flows, see page 30 to see how to bleed air from the system.

## Filters

The filters in your hot tub should be removed and cleaned every 2 weeks with our special Filter Clean concentrated cleanser and typically replaced every 4-6 months (depending upon use). You can clean your filters with the water pressure from the end of a garden hose then rinsed with warm water. This ensures that the water is being filtered properly.

**DO NOT USE BLEACH.** We recommend having replacement filters on hand that can be swapped between cleanings. Doing so enables you to quickly exchange the dirty filters with clean ones and immediately start your hot tub again. Call our order line at 727.573.9611 to order replacement filters and our special Filter Clean concentrated cleanser.

## Jets

Remove and clean the jets as needed using our special our Jet Clean plumbing cleanser, water, and a cloth or soft-bristled brush. Call our order line at 727.573.9611 to order our special our Jet Clean plumbing cleanser.

## Light

Drain the hot tub and clean the light lens as needed using an optical cloth and an eyewear cleaning product specifically designed not to scratch optical surfaces. If the back side of the lens is also dirty remove the rear panel, remove the light from the holder, and clean in this same manner.

## Pillows

Remove and clean the headrest pillows as needed using our Citra Bright Spray Cleaner and our Tub Rub cleaning pad and rinsed thoroughly with warm water. Call our order line at 727.573.9611 to order our Citra Bright Spray Cleaner and our Tub Rub cleaning pad.

## Sanitation

Sanitation level is influenced by two factors:

1. Filter Cycle (filtration) time (see page 25/27)
2. How much you use your hot tub each week

If your water chemistry and water clarity are all proper and your sanitation level is still too low/high, you can adjust the sanitation intensity up/down by adding more/less sanitizer a little at a time and testing the water again after two days.

## Shutdown / Winterizing



Your Fitness Leisure hot tub is designed to operate year round. If you plan to leave your hot tub unused for long periods of time in severely cold weather, you should winterize your hot tub to avoid accidental freezing due to a power or equipment failure.

**We highly recommend that you have a hot tub professional winterize and restart your hot tub.**

**⚠ WARNING:** Damage from improperly winterizing or restarting your hot tub is not covered under your warranty. You can call our customer care center, at 727.573.9611 for recommended service organizations to assist you in properly winterizing your hot tub.

## Surface

The acrylic surface of your hot tub should be cleaned with our Citra Bright Spray Cleaner and our Tub Rub cleaning pad and thoroughly rinsed with warm (not cold) water before refilling. (See also page 31.) Call our order line at 727.573.9611 to order cleaners.

**⚠ WARNING:** NEVER use paint solvents, acids, acetone, benzene, lacquer thinner, toluene, xylene, or similar chemicals to clean your hot tub shell.

## Water Management

Our chemical water purification system is a perfect match for your hot tub.

Depending on usage, the water in your hot tub should be changed every 1-3 months. Upon each change of water it is a good practice to wipe down the hot tub.


If your water quality seems improper, increasing the time the hot tub filters the water (see page 25/27) may clear up your problem.

Below are some answers to common water chemistry questions.

<b>pH</b>	It is common to have pH fluctuations after adding chemicals to your hot tub or after a party. Let your jets run and give your water time to stabilize. 9 times out of 10, your pH will come back into the 7.2-7.8 range on its own.
<b>MILDEW on cover</b>	Mildew usually grows in the folds and seams of your cover and then drips into your hot tub water causing cloudiness and/or odor. Clean with our special Citra Bright Spray Cleaner and then rinse the inside of your cover with clean warm water.
<b>Foamy water</b>	Foam typically results from soap residue on your skin and hair, or laundry detergent residue on clothing. Take a soapless shower and rinse all clothing in warm water prior to bathing.
<b>CLEAR green or brown water</b>	Your "source water" most likely has dissolved heavy metals. When this is the case, use a respected brand of demineralizer found at any local pool/ hot tub store. Using a pre-filter can remove these contaminants before they get into your hot tub (see page 22).
<b>CLOUDY green water</b>	Algae can be resolved by adding a respected brand of algaecide.
<b>CLOUDY white water</b>	Although a normal condition immediately after filling that dissipates after time, with stabilized water this is a visual indication that the total alkalinity or pH or both are at improper levels. Test your water weekly and maintain proper water chemistry (see page 24).
<b>ODOR and/or CLOUDY water</b>	If your water develops an odor and/or cloudiness, clean your cover and filters and try increasing the amount of time the hot tub filters per day by turning your filtration cycle time or duration up.
<b>HEAVY use</b>	After a period of heavy use, your hot tub may cloud. Shock your hot tub with 2 ounces of non chlorine shock and wait 36 hours.

# Specifications

## Endurance (Model ER11)




### Specifications\*

Dimensions	79" Round x 34" H
Seats	5
Water Jets	22
Air Jets	0
Capacity	230 USG /871 L
Dry Weight	475 Lbs/216 Kg
Filled Weight	2390 Lbs/1086 Kg
Electrical	240VAC 32A 60Hz
GFCI	40A

\* Specifications are subject to change without notice.

## Stamina (Model SQ09)




### Specifications\*

Dimensions	76"L x 70"W x 30"D
Seats	5 (1 Lounge)
Water Jets	15
Air Jets	0
Capacity	225 USG /852 L
Dry Weight	425 Lbs/193 Kg
Filled Weight	2300 Lbs/1046 Kg
Electrical	120/240VAC 16/32A 60Hz
GFCI	20/40A

\* Specifications are subject to change without notice.

## Vitalizer (Model OV10D)



### Specifications\*

Dimensions	91"L x 43"W x 30"D
Seats	2
Water Jets	10
Air Jets	0
Capacity	110 USG /416 L
Dry Weight	330 Lbs/150 Kg
Filled Weight	1250 Lbs/568 Kg
Electrical	120VAC 16A 60Hz
GFCI	20A

\* Specifications are subject to change without notice.

---

## Notes

# Warranty

## **Five (5) Year – Fitness Leisure Spa Structural Warranty**

Premium Leisure LLC warrants the Fitness Leisure spa shell structure against the loss of water through the fiberglass laminate of the shell caused by defects in materials and workmanship for a period of Five (5) years from the date of purchase. Contact manufacturer if you have any questions concerning warranty issues.

## **Two (2) Year – Fitness Leisure Spa Surface Warranty**

Premium Leisure LLC Warrants the Fitness Leisure interior acrylic spa surface against blisters, cracks, or delaminating resulting from a defect in the acrylic surface material for a period of Five (2) years from the date of purchase, based on the following formula: Suggested retail price divided by months covered (24), multiplied by months owned = replacement cost.

## **Lifetime Manifold Plumbing Parts Warranty**

Premium Leisure LLC warrants the Fitness Leisure plumbing manifolds, fittings, and parts to be free of defects in materials or workmanship for as long as the original purchaser owns the spa.

## **One (1) Year – Limited Spa Equipment Warranty**

Premium Leisure LLC warrants the Fitness Leisure Spa electrical equipment and components to be free of defects in materials and workmanship for a period of one (1) year on major spa components (electrical system, spa controls, motors) and ninety (90) day, authorized field service on these items. Ninety (90) day (Parts ONLY) Limited Warranty on all optional accessory items (optional cabinets, fixtures, trim kits, skirts, CD & MP3 players, all other music and video devices, ozone, waterfall assembly, LED lighting, etc). All perishable, cosmetic or owner serviceable items, spa cover, light bulb, light lenses, fuses, headrests, cabinet, filters, cover-lift, spa drain, jet inserts, etc are warranted to be free of defects in materials and workmanship at the time of delivery. These items may be covered by a manufacturer's warranty, which may have a longer duration than this Limited Warranty. Premium Leisure LLC may serve as an agent in presenting claims under the manufacturers' warranties, but disclaims any liability there under. In the event Premium Leisure LLC provides parts to replace an alleged defective part under warranty owner will be billed for the cost thereof and credited, minus freight, upon both the defective part being returned to Premium Leisure LLC and the manufacturer of said part accepting warranty claim.

## **WARRANTY PERFORMANCE**

In the event of a suspected defect, under the terms of this Limited Warranty, notify manufacturer. Use all reasonable means to protect the spa from further damage. A service representative will provide the technical labor only, to affect the repair subject to the terms and conditions contained in this Limited Warranty. The service representative may assess reasonable travel charges. Visits to simply diagnose, troubleshoot, or inspect problems are not covered under this Limited Warranty. If we determine that repairs are not feasible due to functional defect, we reserve the right to provide a replacement part or spa in lieu of repair. We will replace with a part of value equal to the original purchase. In such event, owner is responsible for expenses including removal, shipping, and re-installation of the existing or replacement hot tub. The replacement spa or part will carry the balance of the original spa's warranty, if any. Either party's waiver of any breach or failure to enforce any of the terms or conditions of the warranty shall not in any way affect, limit or waive such party's right at any time to enforce strict compliance with every term and condition thereof.

## **LIMITATIONS AND EXCLUSIONS**

This Limited Warranty applies to spas sold after January 1, 2008. This Limited Warranty takes effect from the date the unit was originally purchased or six months from the date of manufacture whichever comes first. This Limited Warranty applies only to the Original Purchaser and terminates with any transfer of ownership. This Limited Warranty does not apply to a spa used for any commercial, rental, club purposes or for any spa used outside of the United States. The purchaser must establish the date of purchase by dated sales invoice of delivery receipt.

This Limited Warranty does not cover damage resulting from abuse, misuse, or neglect including any installation, operation, maintenance or use of the spa other than in accordance with the Owner's Manual of the spa. Damage caused by operation of the spa at water temperatures outside the range of 32 degrees F. and 120 degrees F., damage caused by dirty, clogged, or calcified filter cartridges, damage to the spa surface caused by improper use of chemicals or cleaning agents, allowing un-dissolved spa sanitizing chemicals to lie on the surface, damage caused by improper pH balance or other improper water chemistry, damage caused by failure to provide even and sufficient support for the spa, are considered abuses and may invalidate this Limited Warranty. Damaged caused by repairs or alterations performed by anyone other than an authorized service representative is not covered. Failure caused by accidents, acts of God, nonstructural normal wear and tear, cosmetic blemishes and other causes beyond our control are excluded.

The warranty is in lieu of all other warranties, expressed or implied, including implied warranties of merchantability and fitness for a particular purpose. In no event shall manufacturer be liable for incidental or consequential damages.

## **DISCLAIMERS**

The spa owner is required to provide unencumbered access to the spa for any warranty repair or inspection. Manufacturer shall not be liable for loss of use of spa or other incidental or consequential costs, expenses or damages, which may include, but are not limited to water damage, or the removal of a permanent deck or other customer fixture. Under no circumstances shall we, or any of our representatives be held liable for injury to any person or damage to any property, however arising. This warranty gives you specific legal rights and you may have other rights. No service company, or other party is authorized to change, modify, or extend the terms of this Limited Warranty in any manner what so ever. The jurisdiction and venue for any litigation arising with respect to the transaction evidenced by this warranty shall be the Circuit Court in and for Pinellas County, Florida and Buyer hereby agrees to such jurisdiction and venue.

*fitnessleisure*

6101 45<sup>th</sup> St. N.  
St. Petersburg, FL 33714  
727.573.9611

[www.PremiumLeisure.com](http://www.PremiumLeisure.com)